

## Users Manual - Model: Timeless Open Heart



## 1) START:

Being an automatic watch we suggest you wind it up completely the first time you use it (Position 1) Unscrew the crown and in this position rotate. The crown will need to be wound manually 15 – 20 times to develop a sufficient power reserve to ensure the accuracy of the timepiece. You do not have to repete this action every day while the watch is in use, the watch will charge itself automatically.

## 2) ADJUSTING TIME

Unscrew the crown and pull gently to position "2" then adjust the time. - Important: After any operation make sure to screw the crown back to normal position 1 perfectly straight and closed. If the crown is not perfectly closed and straight it might be possible that water could enter into the watch.