




COLOMER & SONS

Users Manual - Model: Sport Chrono



1) START

Being an automatic watch we suggest you wind it up completely the first time you use it (Position 1) Unscrew the crown and in this position rotate the crown will need to be wound manually 15 – 20 times to develop a sufficient power reserve to ensure the accuracy of the timepiece. You do not have to repeat this action every day while the watch is in use, the watch will charge itself automatically.

2) SETTING OF THE TIME

Unscrew and pull out the crown smoothly (Position 2) and move the hands to the desire time.

3) USING THE CHRONOGRAPH

To measure any kind of phenomenon, simply press the top right button (A) for the chronograph to start working, to stop it press the same button (A) once again. To return the chrono hand to zero, press the bottom button (B). If you measure more than a minute, you will see that the dragging counter minute at 3 o'clock will start to count them, going up to 30 minutes.

- Important: After any operation make sure to screw the crown back to normal position 1 perfectly straight and closed. If the crown is not perfectly closed and straight it might be possible that water could enter into the watch.
