




COLOMER & SONS

Users Manual - Model: Classic Power Reserve



1) START

Being an automatic watch we suggest you wind it up completely the first time you use it (Position 1) Unscrew the crown and in this position rotate the crown will need to be wound manually 15 – 20 times to develop a sufficient power reserve to ensure the accuracy of the timepiece. You do not have to repeat this action every day while the watch is in use, the watch will charge itself automatically.

2) ADJUSTING DAY

Adjust the day by rotating the crown counter-clockwise in "2" position.

3) ADJUSTING DATE

Adjust the date by rotating the crown clockwise in "2" position.

4) ADJUSTING TIME

Rotate the crown in "3" position and adjust the standard time. Then check if it is morning or afternoon and adjust correctly.

5) ADJUSTING MONTH

Push the button "A" and adjust the month.

If the button is not pushed to the end, the month is not changed perfectly.

- Important: After any operation make sure to screw the crown back to normal position 1 perfectly straight and closed. If the crown is not perfectly closed and straight it might be possible that water could enter into the watch.
